

A yellow and black arrow-shaped logo with the text "BETTER BARRIERS" in bold black letters.

**BETTER BARRIERS**



# NATURAL STONE & RETAINING WALLS HARDSCAPE FABRIC

A blue badge with a white border containing the text "LIFETIME GUARANTEE" in white capital letters.

**LIFETIME  
GUARANTEE**

Better Barriers™ is Canada's leader in hardscape fabrics. When applied correctly, this product stabilizes and separates soil profiles and will provide lifetime stability for your hardscape projects.

## INSTALLATION INSTRUCTIONS

### *For Permanent Perennial Gardens*

1. Roll out our Better Barriers™ Hardscape Fabric and cut to length. When overlapping the product allow at least a 7.6 cm - 12.7 cm (3 - 5 in) overlap.
2. For new plants cut an X in the product large enough to plant through. If plants exist cut an X large enough to slip the product over the plant. If very large shrubs or trees are present, cut a slit from the edge of the fabric to the base of the tree and slip fabric around the base. Since the slits will tend to expose the soil below, it is recommended that the slit be overlapped with strips of fabric wide enough to overlap the slit by 7.6 cm - 12.7 cm (3 - 5 in) on each side.
3. During installation it is recommended that you use our Quest® Fabric & Garden Staples to securely anchor each section of the Better Barriers™ product to the soil.
4. Cover the fabric with a minimum of 7.6 cm (3 in) of bark or mulch. If covering with stone, marble chips or crushed clay, then cover with at least 7.6 cm - 10 cm (3 - 4 in) of material and use enough small-sized pieces to fill in the resulting spaces. All hardscape fabrics are weakened by U.V. rays of the sun which makes complete coverage important for long-term satisfying results.

### *For Hardscape Projects*

1. Roll out our Better Barriers™ Hardscape Fabric on prepped soil and cut to length. When overlapping the product allow at least a 7.6 cm - 12.7 cm (3 - 5 in) overlap.
2. During installation it is recommended that you use our Quest® Fabric & Garden Staples to securely anchor each section of the Better Barriers™ product to the soil.
3. Apply the aggregate profile suitable for your project, prep and complete.